



Components

- | | |
|-----------------------|------------------|
| (8) - Screw | (1) - Bench Back |
| (1) - Left Bench End | (1) - Bench Seat |
| (1) - Right Bench End | |

Instructions

1. Attach Bench Seat to Left Bench End using 2 of the provided Screws.
2. Attach Bench Back to Left Bench End using 2 of the provided Screws.
3. Repeat steps 1 and 2 with the Right Bench End.

Notes

Over time, as natural teak is exposed to the elements, it gradually changes color from the honey color of new teak to a silver-gray patina which distinguishes finely aged, outdoor teak. This color transformation does not affect the durability of the teak bench or the wood itself.

To maintain the smooth finish and golden brown color, sand your teak bench regularly. Teak oil may be applied to prolong time between sandings. If you apply teak oil, follow the container instructions. Teak oil does not prolong the life of teak; it simply maintains the golden brown color.

Cover your teak furniture during winter months or move into covered area.